

# Troubleshooting your panic button system

## System Trouble Menu:

When your panic button system is in trouble mode, the keypad will sound a periodic beep to alert you of the trouble. To view the system trouble log and silence the notification press \* then 2 to enter the systems trouble menu. To exit the trouble menu simply press # three times.



### *Trouble code definitions:*

1	Service required (Low battery)
2	Power failure
3	Phone line trouble
4	Fail to communicate
5	Zone fault
6	Zone tamper
7	Wireless device low battery
8	Loss of system time and date

## Setting the system clock:

When setting the system time and date you will need your system master code.

1. Press \* then 6 on your system keypad
2. Enter your master code (XXXX)
3. Press the 1 button
4. Enter the time and date in 24hr format (HH:MM MM/DD/YY)
5. When you have finished entering the above string of numbers press the # button three (3) times.

**Note:** If system troubles other than "Loss of system time and date" exist, please contact us at

Spectrum Fitness Services  
888-903-7648 Ext 331  
Or visit us at  
[www.keytagclub.com/support](http://www.keytagclub.com/support)